

# **PET**

*2 wheel lithium scooter*

Read this manual completely  
before assembling and riding  
our PET



Always wear a Helmet!

## **Owner's Manual**

Tel. 1-707-521-9257  
[www.petscooters.com](http://www.petscooters.com)

# **PET**

# Table of Contents

Technical Information-----	1
Warning Statement-----	2
Read Before Riding-----	3
List Of Parts-----	4
Front Bar-----	6
Opening and Folding The PET -----	7
Charging The Batteries-----	8
Safety-----	9
Maintenance-----	11
Trouble Shooting Guide-----	12
Warranty-----	14

---

Model No.	PET LITHIUM 2 WHEEL
Product size	42.5 L x 22.4 W x 43.3 H inch (108 L x 57 W x 110 H cm)
Type of motor	DC brushless motor
Motor power	36V 350W
Battery type	Li battery
Battery capacity	36V 10Ah
Charger	110V-240V, UL approved
Charging time	5-6 hours
Max. speed	Up to 13.2 MPH (22 km/h)
Single charge	Up to 22.8 MILES (38 km)
Max capacity	264 LBS (120 kg)
Net weight	35 LBS (15.9 kg)
Package size	45.3 L x 12 W x 13.6 H inch (115 L x 30.6W x 34.5 H cm)



## IMPORTANT!

Before you operate your PET please read carefully:

**YOUR EXISTING INSURANCE POLICY MAY NOT PROVIDE COVERAGE FOR ELECTRIC VEHICLES. YOU SHOULD CONTACT YOUR INSURANCE AGENT TO DETERMINE IF COVERAGE IS PROVIDED.**



Do not ride this scooter until you read and thoroughly understand the owner's manual. It contains information critical to your safety. If you have questions about the operation of this scooter, you should consult your authorized dealer.



It is extremely important that you follow the safety guidelines contained in this manual in order to insure maximum safety.



Failure to comply with the standards outlined in this manual could result in fire and/or serious injury.



PET is not liable for any damage or injuries caused by unsafe or faulty repairs. Any repairs made to this product by unauthorized service technicians are the sole responsibility of the owner.



Our products are designed to be ecologically conscious, please dispose of used batteries in compliance with local laws.

## WARNING

THE ELECTRIC PET IS NOT A TOY AND SHOULD NOT BE OPERATED BY ANY ONE UNDER 12 YEARS OLD.

### Safety Instruction

*(Please take note of the followings before each ride)*

- The maximum weight capacity is 220 LBS.
- Only one person at a time should ride.
- Always wear protective gear including knee and elbow pads and an approved safety helmet when riding the PET
- Before riding be sure to check that all pivot points, locking buttons, quick releases, and latches are secured properly.
- The power switch lock must be in the "off" position when the PET is being charged.
- Do not use the PET when it is raining.
- Do not place the battery near heat or fire.
- Do not expose the charger to water or any moisture.
- Check if battery is properly charged and installed.
- Charge battery after each use.
- Always ride on dry paved surfaces. Gravel, wet and uneven surfaces are a hazard.

**Check if all tires are properly inflated.**



- 
- 1 Throttle
  - 2 Power indicator
  - 3 Power switch
  - 4 Brake lever
  - 5 Seat
  - 6 Fold lock
  - 7 Car body
  - 8 Rear fender
  - 9 Motor
  - 10 Rear tire
  - 11 Bracket
  - 12 Front tire
  - 13 Integrated light
  - 14 Lift lock



- 1 Brake lever
- 2 Integrated light switch
- 3 Horn switch
- 4 Power indicator
- 5 Power switch
- 6 Throttle

# Opening and Folding The PET PET

---

1. Pull out the fold lock(show in Picture1), then pull down the direction rod until the fold lock is locked.



Picture 1

2. Assemble the folding bar



Picture 2



picture 3

**Note: Folding step is as inverted order of opening.**

---

The battery can be charged directly in the scooter.

- a. Switch off the power
- b. Attach one end of the charger to the scooter charging hole(make sure there is no water in the hole)
- c. Attach plug to power socket
- d. Red light of the charger on indicate it is charging
- e. When red light turns to green, battery is full
- f. Disattach the plug from the socket first and then remove another end from scooter charge hole



---

## 1. Attention on Electric Scooter

a). Put it in a safe place where children cannot reach when charging

b). Do not drive it if power not full as it is of no enough energy to support loading and easy to fall and get hurt, and also harm to battery life

c). It is dangerous to use non-original charger or battery maybe damaged and do not use our charger to charge other types of batteries.

d). Do not disassemble the charger because the charger contains high-voltage circuit

e). Prevent liquid and metal particles penetrate inside the charger when using and store, beware of falling and impact to avoid damage

f). Please use the charger in dry, ventilated environments and do not affix anything on the charger while charging

g). Please stop charging immediately and sent charger and battery to the dealership for repair if there is smell odor or the temperature is too high in the process of charging

## 2. Safety Checks Before Riding

a). check the battery's voltage and be sure it is in normal condition

b). check the front wheel and rear wheel, the handle bar, the fold bar to make use all parts are tightened and all bolts are in tight condition

c). check the reliability of the brake system

---

### 3. Safety Parking

a). Please turn the power off when you get off the scooter to walk by to prevent unintentional touch on the dynamic acceleration in case the scooter suddenly goes forwarder and lead accident happened

b). Please turn off the power when you stop riding and please make regular maintenance and cleaning to keep your scooter in top condition

c). Please store your scooter away from the raining

- 
1. A periodic self-test project
    - a).Front and rear wheel's nuts in the correct position and tightly
    - b).The tire tread whether badly worn, whether cracking. Various parts of the connection whether ok, brake lines zipper whether be used in lubrication condition.
    - c).Electrical system is in good condition
    - d).Suspension fork's screws in the correct position
  2. Cleaning Instructions
    - a)Prohibit rinse by water to avoid accidents because of internal electronic components and circuit caused by wetting
    - b)Use a mild detergent; wipe the surface with a rag at the dirt, then wipe with cadres.
    - c)Prohibit to the oiling the rear brake and tire
  3. Maintenance and Adjustment
    - a)Always check the handlebar if get loose.
    - b)Always check the performance of the brakes whether good and timely adjustments.

Problem	Cause	Solution
The trigger of the scooter does not work when pause.	Check the brake whether reset, Brakes whether still in the automatic power-off state, side support whether put away.	Reset the brake Put away the side support
Travel speed a little slow	Check the throttle could be fully adjusted	Fix or change throttle
	Battery whether full	charge
Display light and motor not working	low voltage of battery	Charge
	End of battery life	Replace battery
	controller broken	Replace controller
Motor on and off automatically	poor contact of battery	Adjust or polish the contact
	Power lock burned	Replace lock

---

Short distance of one charge	End of battery life	Replace battery
	Voltage not matching	Maintain or replace battery
Battery charge failed or not be fully charged	End of battery life	Replace battery
	no output of charger	Replace charger
	Bad contact between charger and plug	Replace plug

---

The Limited Warranty does not cover or apply to the following: Normal wear and tear; any damage, failure and/or loss caused by accident, misuse, neglect, abuse and/or failure to follow instructions or warnings as stated on the product or in the applicable owner's manual or other printed materials provided with the product; damage, failure and/or loss caused by the use of the product in any other manner for which such products were not specifically designed.

PET warrants each new PET product for six (6) months according to the following terms. Batteries and tires are warranted for three (3) months. This warranty extends to the original retail purchaser only and commences on the date of the original retail purchase. Any part of the PET product manufactured or supplied by PET and found in the reasonable judgment of PET to be defective in material or workmanship will be repaired or replaced by an authorized PET service dealer without charge for parts or labor. PET is responsible for the expense of delivering the warranty replacement parts. However, if the customer chooses not to replace the parts, the expense of delivering the PET product to the factory or authorized service dealer for warranty

work or the expense of returning it back to the owner after repair or replacement will be paid for by the owner. PET's responsibility in respect to claims is limited to making the required repairs or replacements and no claim of breach of warranty shall be cause for cancellation or rescission of the contract of sale of any PET product. Proof of date of purchase will be required by the dealer to substantiate any warranty claim. An authorized PET service dealer must perform all warranty work. The warranty is limited to thirty (30) days from the date of purchase for any PET product that is used for rental demonstration or commercial purposes or any other income producing purpose. This warranty does not cover any PET product that has been subject to misuse, neglect, negligence or accident, or has been operated in any way contrary to the operating instructions as specified in the PET owner's manual. This warranty does not apply any damage to the PET product that is the result of improper maintenance or to any PET product that has been altered or modified so as to adversely affect the products operation, performance or durability or that has been altered or modified to change its intended use. This warranty does not extend to repairs made necessary by normal

wear and or by use of parts that are incompatible with PET products. In addition this warranty does not cover items that experience normal wear and tear. PET reserves the right to improve the design of the product without assuming any obligations to modify any product previously manufactured. All warranties are limited in duration to the six (6) months warranty period. Any such implied warranties including merchantability, fitness for a particular purpose or otherwise are disclaimed in their entirety after the expiration of the appropriate thirty day warranty period. PET's obligation under this warranty is strictly and exclusively limited to the repair and replacement of defective parts and PET does not assume any other obligation. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. PET assumes no responsibility for incidental consequential or other damages including but not limited to expense of returning the PET product to an authorized service dealer and expense of delivering it back to the owner. Mechanic's travel, time telephone charges, rental of a like product during the time the warranty service is being performed travel loss or damage to personal property, loss of revenue, loss of time, or

inconvenience. Some states do not allow the exclusion or limitation of incidental or consequential damages so the above limitations may not apply to you.

## **WHAT PET WILL DO:**

PET will, at its sole option, either repair, replace or refund the purchase price of any unit that does not conform to this limited warranty. PET may choose at its option to use functionally equivalent reconditioned, refurbished or new units or parts or any units. You are responsible to get the unit back to PET.

## **HOW TO GET WARRANTY SERVICE:**

To obtain warranty service, please call or fax to the following telephone numbers for PET Customer Service - warranty repair

Tel. [1-707-521-9257](tel:1-707-521-9257)

[www.petscooters.com](http://www.petscooters.com)

## **DO NOT RETURN YOUR PRODUCT TO ANY ADDRESS.**

Please call or write for the location of the PET authorized service center nearest you and for the procedures for obtaining warranty claims.